§ 195.569

- (b) *Installation*. You must install test leads as follows:
- (1) Locate the leads at intervals frequent enough to obtain electrical measurements indicating the adequacy of cathodic protection.
- (2) Provide enough looping or slack so backfilling will not unduly stress or break the lead and the lead will otherwise remain mechanically secure and electrically conductive.
- (3) Prevent lead attachments from causing stress concentrations on pipe.
- (4) For leads installed in conduits, suitably insulate the lead from the conduit.
- (5) At the connection to the pipeline, coat each bared test lead wire and bared metallic area with an electrical insulating material compatible with the pipe coating and the insulation on the wire
- (c) Maintenance. You must maintain the test lead wires in a condition that enables you to obtain electrical measurements to determine whether cathodic protection complies with \$195.571.

§ 195.569 Do I have to examine exposed portions of buried pipelines?

Whenever you have knowledge that any portion of a buried pipeline is exposed, you must examine the exposed portion for evidence of external corrosion if the pipe is bare, or if the coating is deteriorated. If you find external corrosion requiring corrective action under §195.585, you must investigate circumferentially and longitudinally beyond the exposed portion (by visual examination, indirect method, or both) to determine whether additional corrosion requiring remedial action exists in the vicinity of the exposed portion.

§ 195.571 What criteria must I use to determine the adequacy of cathodic protection?

Cathodic protection required by this Subpart must comply with one or more of the applicable criteria and other considerations for cathodic protection contained in paragraphs 6.2 and 6.3 of NACE SP 0169 (incorporated by reference, see §195.3).

 $[{\rm Amdt.}\ 195\text{--}94,\ 75\ {\rm FR}\ 48607,\ {\rm Aug.}\ 11,\ 2010]$

§195.573 What must I do to monitor external corrosion control?

- (a) *Protected pipelines*. You must do the following to determine whether cathodic protection required by this subpart complies with §195.571:
- (1) Conduct tests on the protected pipeline at least once each calendar year, but with intervals not exceeding 15 months. However, if tests at those intervals are impractical for separately protected short sections of bare or ineffectively coated pipelines, testing may be done at least once every 3 calendar years, but with intervals not exceeding 39 months.
- (2) Identify not more than 2 years after cathodic protection is installed, the circumstances in which a close-interval survey or comparable technology is practicable and necessary to accomplish the objectives of paragraph 10.1.1.3 of NACE SP 0169 (incorporated by reference, see § 195.3).
- (b) *Unprotected pipe*. You must reevaluate your unprotected buried or submerged pipe and cathodically protect the pipe in areas in which active corrosion is found, as follows:
- (1) Determine the areas of active corrosion by electrical survey, or where an electrical survey is impractical, by other means that include review and analysis of leak repair and inspection records, corrosion monitoring records, exposed pipe inspection records, and the pipeline environment.
- (2) For the period in the first column, the second column prescribes the frequency of evaluation.

Period	Evaluation frequency
Before December 29, 2003	At least once every 5 cal- endar years, but with inter- vals not exceeding 63 months.
Beginning December 29, 2003.	At least once every 3 cal- endar years, but with inter- vals not exceeding 39 months.

(c) Rectifiers and other devices. You must electrically check for proper performance each device in the first column at the frequency stated in the second column.

Device	Check frequency
Rectifier	At least six times each calendar year, but with intervals not exceeding 2½ months.
Reverse current switch. Diode. Interference bond whose fail- ure would jeopardize struc- tural protection.	
Other interference bond	At least once each calendar year, but with intervals not exceeding 15 months.

- (d) Breakout tanks. You must inspect each cathodic protection system used to control corrosion on the bottom of an aboveground breakout tank to ensure that operation and maintenance of the system are in accordance with API Recommended Practice 651. However, this inspection is not required if you note in the corrosion control procedures established under §195.402(c)(3) why compliance with all or certain operation and maintenance provisions of API Recommended Practice 651 is not necessary for the safety of the tank.
- (e) Corrective action. You must correct any identified deficiency in corrosion control as required by §195.401(b). However, if the deficiency involves a pipeline in an integrity management program under §195.452, you must correct the deficiency as required by §195.452(h).

[Amdt. 195–73, 66 FR 67004, Dec. 27, 2001; 67 FR 70118, Nov. 20, 2002, as amended by Amdt. 195–86, 71 FR 33411, June 9, 2006; Amdt. 195–94, 75 FR 48607, Aug. 11, 2010]

§ 195.575 Which facilities must I electrically isolate and what inspections, tests, and safeguards are required?

- (a) You must electrically isolate each buried or submerged pipeline from other metallic structures, unless you electrically interconnect and cathodically protect the pipeline and the other structures as a single unit.
- (b) You must install one or more insulating devices where electrical isolation of a portion of a pipeline is necessary to facilitate the application of corrosion control.
- (c) You must inspect and electrically test each electrical isolation to assure the isolation is adequate.
- (d) If you install an insulating device in an area where a combustible atmos-

phere is reasonable to foresee, you must take precautions to prevent arcing.

(e) If a pipeline is in close proximity to electrical transmission tower footings, ground cables, or counterpoise, or in other areas where it is reasonable to foresee fault currents or an unusual risk of lightning, you must protect the pipeline against damage from fault currents or lightning and take protective measures at insulating devices.

§ 195.577 What must I do to alleviate interference currents?

- (a) For pipelines exposed to stray currents, you must have a program to identify, test for, and minimize the detrimental effects of such currents.
- (b) You must design and install each impressed current or galvanic anode system to minimize any adverse effects on existing adjacent metallic structures

§ 195.579 What must I do to mitigate internal corrosion?

- (a) General. If you transport any hazardous liquid or carbon dioxide that would corrode the pipeline, you must investigate the corrosive effect of the hazardous liquid or carbon dioxide on the pipeline and take adequate steps to mitigate internal corrosion.
- (b) Inhibitors. If you use corrosion inhibitors to mitigate internal corrosion, you must—
- (1) Use inhibitors in sufficient quantity to protect the entire part of the pipeline system that the inhibitors are designed to protect;
- (2) Use coupons or other monitoring equipment to determine the effectiveness of the inhibitors in mitigating internal corrosion; and
- (3) Examine the coupons or other monitoring equipment at least twice each calendar year, but with intervals not exceeding $7\frac{1}{2}$ months.
- (c) Removing pipe. Whenever you remove pipe from a pipeline, you must inspect the internal surface of the pipe for evidence of corrosion. If you find internal corrosion requiring corrective action under §195.585, you must investigate circumferentially and longitudinally beyond the removed pipe (by visual examination, indirect method,